




T41200BS – 4 Inch Belt Sander 1200W





T41200BS – 4 Inch Belt Sander 1200W

No.	Description
1	CROSS RECESS HEAD SCREW
2	ROLLER COVER
3	NUT
4	DRUM
5	RING
6	ROLLER SLEEVE
7	BEARING
8	CERAMIC
9	AL BRACET
10	NEEDLE BEARING
11	WASHER
12	OIL SEALING
13	SHAFT
14	BEARING
15	GEAR COVER
16	BIG PULLEY
17	CROSS RECESS HEAD SCREW
18	CROSS RECESS HEAD SCREW
21	KNOB SPRING
22	SCREW
23	EXTERNAL CIRCLIP
24	BIG GEAR
25	KEY PIECE
26	WAVE WASHER
27	GEAR SHAFT
28	FORK SPRING
29	PLASTIC SPRING SLEEVE
30	SPRING SLEEVE
31	WASHER
32	SPANNER BLOCK
33	CROSS RECESS HEAD SCREW
34	CROSS RECESS HEAD SCREW
35	CLAMP DEVICE



T41200BS – 4 Inch Belt Sander 1200W

36	SPRING
37	PIN
38	SPANNER SLEEVE
39	SPANNER
40	ROLLER
41	BEARING
42	WASHER
43	FORK
44	ROLLER SHAFT
45	HEX NUT
46	POWER CORD
47	CORD PROTECTOR
48	SELF TAPPING SCREW
49	CORD CLAMP
50	CAPACITOR
51	SWITCH
52	WASHER
53	SPRINGING WASHER
54	CROSS RECESS HEAD SCREW
55	DUST BAG
56	ADAPTOR FOR BAG
57	SMALL PULLEY
58	SELF TAPPING SCREW
60	SELF TAPPING SCREW
61	CROSS RECESS HEAD SCREW
62	BELT COVER
63	BELT
64	LEFT HOUSING
65	BEARING
66	BEARING COVER
67	SELF TAPPING SCREW
68	ARMATURE 230V
69	BEARING
70	FAN BAFFLE
71	MIDDLE HOUSING



T41200BS – 4 Inch Belt Sander 1200W

72	SCREW
73	FIELD
74	SELF TAPPING
75	DUST FLOW COVER
76	RIGHT HOUSING
77	SELF TAPPING SCREW
78	SELF TAPPING SCREW
79	SELF TAPPING SCREW
80	BASE SHEET
81	WASHER
82	WASHER
83	CROSS RECESS HEAD SCREW
84	FILTER PIECE
85	BASE
86	WASHER
87	CROSS RECESS HEAD SCREW
89	BRUSH HOLDER
90	CARBON BRUSH ASSEMBLY WITH SPRINGS
91	BRUSH COVER
92	RUBBER BIT
93	SELF TAPPING SCREW
94	WASHER
95	CONNECTOR WIRE
96	PCB BOARD
98	HEX NUT